

Moulding Installation Instructions

Materials needed;

Safety Glasses

Tape Measure

Hammer or Pneumatic Nailer

Miter Saw

Hammer

Nail Countersink

Corrosion-resistant Finishing Nails and Screws

Caulk Gun

PL Premium Adhesive

Caulk or Wood Filler

Sandpaper

Pencil

Latex or Oil Base Paint

Installation Step;

1. DRAW A LAYOUT OF THE ROOM

Begin by drawing a simple layout of the room. Determine the location and quantities of the parts you need . Hint: Use divider blocks to create your own special design. They hide the seams, adding beauty and making the Miter less Crown Moulding System easy to install.

2. APPLY ADHESIVE AND SET CORNER INTO PLACE

Starting with one of the corners, apply a bead of quality urethane base construction adhesive (we recommend PL premium brand adhesive) to the backside and all contact points of the miter less corner and set it into place. Snug the wall and the ceiling.



3. FASTEN CORNER PIECES

Fasten the corner piece with nails or screws, hiding nails or screws by driving them into decorative or recessed areas of the corner piece. Continue with all other inside and outside corners in the room.

4. INSTALL DIVIDER BLOCKS

Apply adhesive to the back and side of the first moulding divider block. Set it into place tight against the miter less corner and fasten with nails or screws. Install a divider block on both sides of all corners in the room. using your layout as a guide, fasten all additional divider blocks in place.